

ENCANTO – PRODUCT PERFORMANCE

PROPERTY	STANDARD	SPECIFICATION ACHIEVED	
		LOCO	ONDA
Composition	N/A	100% Polyester - Antimicrobial, SR, Waterproof, FR	
Weight (g/m2)	(+/- 5%)	409 gsm	
Width (cm)	Flat measure	137cm	
Fabric Type	N/A	Woven Upholstery	
Tensile Strength (N)	BS EN ISO 13934-1	>600n	
Tear Strength (N)	BS EN ISO 13937-3	>25n	
Seam Slippage (mm)	BS EN ISO 13936-2	<4mm	
Martindale Abrasion (cycles)	BS EN ISO 12947-2	50,000	
Martindale Pilling (cycles)	BS EN ISO 12945-2	Grade 5	
Dimensional Stability to Washing	BS EN ISO 6330:2012	N/A	
Colour Fastness to Rubbing (grade)	BS EN ISO 105 X12	4/5	
Colour Fastness to Light (grade)	BS EN ISO 105 B02	5	
Flammability	Insert appropriate standards	BS5852 Crib 5 IMO A652 Part 8 Upholstery	
End Uses	Upholstery		
Cleaning instructions	Vacuum the surface regularly to remove dust and dirt Regular cleaning will help to keep the fabric appearance and prolong its useful life. Wipe clean with warm water for most spillages. Use mild soap for more stubborn dirt. Ensure all cleaning products are removed from the surface as this can inhibit the SR performance. Body fluids and extreme soiling should be removed immediately with cold water, then appropriate infection control protocol should be applied. Via extensive trials, Skopos have found enzyme-based cleaners such as Bio Hygiene offer the best results. Never use polish, stain remover, solvent or abrasive cleaning cloths. Do not machine wash, dry clean or tumble dry. NB It is always advised to check the suitability of any upholstery cleaning fluid by applying to an area out of sight. Avoid any contact with bleach based cleaning agents as this can cause significant damage to the fabric It is the contractor's responsibility to ensure all cleaning instructions are passed onto the end user		

APPSKD020A2 ISSUE 5 30 NOVEMBER 2022

SPECIALIST IN THE SUPPLY AND DESIGN
 OF FR FABRICS AND FURNISHINGS FOR
 THE INTERNATIONAL CONTRACT MARKET

Installation Instructions	<u>Usable width of fabric</u> Our fabric widths are quoted as the usable width only. The supplied fabric will be wider, incorporating the selvedge. This selvedge on either side of the fabric is finished to prevent unravelling and is often made of different and/or heavier threads than the woven fabric and sometimes in a different weave. The selvedge should be cut off and discarded and not used in the construction of your item. Incorporating the selvedge, even if only slightly, can lead to seam slippage over time. <u>Sunlight Degradation to fabrics</u> The process of sunlight fading fabrics is called photodegradation. This photodegradation breaks down the chemical bonds of dyes in fabrics fading them over time and, in turn, degrades the fabric itself. Prolonged exposure to sunlight will, in the long-term, make fabric brittle and accelerate disintegration. Bold colours are more prone to fading than lighter colours and fading will appear faster. It is widely recommended that for windows orientated such that they have a high exposure to sunlight (for example South facing windows, in the UK), UV reflective glazing is installed, or UV reflecting window film is installed where this is not practical. For window coverings, lining curtains is also an effective way to reduce the sunlight exposure onto face-fabrics, although it should be noted that the linings themselves will then absorb all light and are therefore likely to need replacing over time. Similarly, installing sheers will reflect an element of sunlight and allow occupants privacy in the room. Allowing extra width on tracks or poles allows the fabric to be pulled clear of the windows when curtains are open, preventing excessive sunlight exposure. <u>Use of glue with Upholstery Fabrics</u> Spray adhesives should be tested on a cutting of fabric prior to use. Spray adhesives have varying time to allow movement before setting. Once set, movement may damage the flame retardant backing. Hot glue should also be tested on a cutting of fabric prior to use. Hot glues have varying temperature thresholds and have been known, in some cases, to damage fabric fibres and/or fabric backing. The weave structure is also an important factor in whether glue is an appropriate method for fixing upholstery fabric. Some fabrics are inherently flame retardant and therefore do not require an additional flame-resistant backing and some flame-retardant backings are made from natural, absorbent fibres; as such these fabrics may have an open weave, which could allow some types of glue to penetrate to the surface of the fabric and/or effect the handle of the finished fabric. Always test a cutting of fabric to ensure that the glue chosen does not penetrate or alter the handle of the fabric to an unacceptable degree. <u>Use of Upholstery fabric on loosely supported or large expanses of foam</u> Some fabrics are flexible in weave; the benefit of this is that the fabric is easier to work around tight angles and corners, however for such fabrics care should be taken to judge their suitability for large expanses of foam or for use in loosely supported cushions. Fabric with higher stretch will naturally do so under high loads. When used on un-sprung bases and/or over larger expanses of foam, the pressure and load of weight at the centre of the fabrics is high, and as a result, flexible fabrics may 'bag' or deform over time, this is especially so when cushions are sewn or otherwise fixed into position, as the fabric has less chance to re-gain it's

	structure. It is always advisable to test the flexibility and re-gain of the fabric chosen for the use to which it is being put to assess suitability. Samples of fabrics are available free of charge, upon request
--	--