

BERG – PRODUCT PERFORMANCE August 25

PROPERTY	STANDARD	SPECIFICATION ACHIEVED
Composition	N/A	100% Trevira CS
Weight (g/m2)	(+/- 5%)	460gsm
Width (cm)	Flat measure	140cm
Fabric Type	N/A	Textured Weave
Tensile Strength (N)	BS EN ISO 13834	>600N
Tear Strength (N)	BS EN ISO 13937	>25N
Seam Slippage (mm)	BS EN ISO 13936	<6mm
Martindale Abrasion (cycles)	BS EN ISO 12947	40,000 rubs
Martindale Pilling (cycles)	BS EN ISO 12945	Grade 4-5
Wash Shrinkage (30°C)	BS EN ISO 6330	≤ 3%
Colour Fastness to Water (grade)	BS EN ISO 105 E01	>4
Colour Fastness to Rubbing (grade)	BS EN ISO 105 X12	Dry - >4 Wet - >4
Colour Fastness to Light (grade)	BS EN ISO 105 B02	Grade 6
Colour Fastness to Washing to care instructions (grade)	BS EN ISO 105 CO6	>4
Colour Fastness to Dry Cleaning (grade)	BS EN ISO 105 D01	Grade 4-5
Flammability	BI MI Class Uno BS5867 part 2 Type C BS7175 0, 1 and 5 BS7176 Medium Hazard (Cig and Match, Crib 5) IMO Part 7 (Drape) IMO Part 8 (using 36kg CMHR foam) IMO Part 9 (Bedding)	
End Uses	Curtains, Bedding, Cushions and Upholstery	
Cleaning/care instructions	DRAPE/BEDDING Wash at 30°C Gentle Cycle Do not bleach Low heat iron (One dot) Dry clean (sensitive conditions) Do not tumble dry Before laundering curtains, always remove all curtain hooks and un-draw the heading tapes. Washing inside out will assist to reduce wear, maintain the original colour and ultimately increase the serviceable life of the product. UPHOLSTERY Vacuum the surface regularly to remove dust and dirt	

	Regular cleaning will help to keep the fabric appearance and prolong its useful life. Wipe clean with warm water for most spillages. Use mild soap for more stubborn dirt. Never use polish, stain remover, solvent or abrasive cleaning cloths. Do not machine wash, dry clean or tumble dry. NB It is always advised to check the suitability of any upholstery cleaning fluid by applying to an area out of sight NB It is always advised to check the suitability of any upholstery cleaning fluid by applying to an area out of sight. Avoid any contact with bleach-based cleaning agents as this can cause significant damage to the fabric.
Installation Instructions	<u>Sunlight Degradation to fabrics</u> The process of sunlight fading fabrics is called photodegradation. This photodegradation breaks down the chemical bonds of dyes in fabrics fading them over time and, in turn, degrades the fabric itself. Prolonged exposure to sunlight will, in the long-term, make fabric brittle and accelerate disintegration. Bold colours are more prone to fading than lighter colours and fading will appear faster. It is widely recommended that for windows orientated such that they have a high exposure to sunlight (for example South facing windows, in the UK), UV reflective glazing is installed, or UV reflecting window film is installed where this is not practical. For window coverings, lining curtains is also an effective way to reduce the sunlight exposure onto face-fabrics, although it should be noted that the linings themselves will then absorb all light and are therefore likely to need replacing over time. Similarly, installing sheers will reflect an element of sunlight and allow occupants privacy in the room. Allowing extra width on tracks or poles allows the fabric to be pulled clear of the windows when curtains are open, preventing excessive sunlight exposure. <u>Use of glue with Upholstery Fabrics</u> Spray adhesives should be tested on a cutting of fabric prior to use. Spray adhesives have varying time to allow movement before setting. Once set, movement may damage the flame retardant backing. Hot glue should also be tested on a cutting of fabric prior to use. Hot glues have varying temperature thresholds and have been known, in some cases, to damage fabric fibres and/or fabric backing. The weave structure is also an important factor in whether glue is an appropriate method for fixing upholstery fabric. Some fabrics are inherently flame retardant and therefore do not require an additional flame-resistant backing and some flame-retardant backings are made from natural, absorbent fibres; as such these fabrics may have an open weave, which could allow some types of glue to penetrate to the surface of the fabric and/or effect the handle of the finished fabric. Always test a cutting of fabric to ensure that the glue chosen does not penetrate or alter the handle of the fabric to an unacceptable degree. <u>Use of Upholstery fabric on loosely supported or large expanses of foam</u> Some fabrics are flexible in weave; the benefit of this is that the fabric is easier to work around tight angles and corners, however for such fabrics care should be taken to judge their suitability for large expanses of foam or for use in loosely supported cushions. Fabric with higher stretch will naturally do so under high loads. When used on un-sprung bases and/or over larger expanses of foam, the pressure and load of weight at the centre of the fabrics is high, and as a result, flexible fabrics may 'bag' or deform over time, this is especially so when cushions are sewn or otherwise fixed into position, as the fabric has less chance to re-gain its structure. It is always advisable to test the flexibility and re-gain of the fabric chosen for the use to which it is being put to assess suitability. Samples of fabrics are available free of charge, upon request. It is the contractor's responsibility to ensure all cleaning and installation instructions are passed onto the end user.